

# CRE-56802 MINI ON-BOARD CAMERA

## Operating manual for 2.4G wireless camera

FCC/CE APPROVAL

### Characters:

Wireless transmitting Audio & Video, small size, light weight, low power consumption, high sensibility, easy operation and installation.

### Operation manual:

1. Connect the antenna with receiver;
2. Plug power jack of DC 12V power supply into the power socket of the receiver (the power indicator is on);
3. Connect the output of receiver with monitor with AV wire;
4. Plug power jack of DC 8V power into the power socket of the camera (battery of the same voltage is acceptable);
5. Dial receiver's channel to corresponding channel of wireless camera.
6. Adjust the lens of the camera to best position.

### Function:

Suitable for monitoring children, elders and houses, companies, shops and factories, etc.

### Notice:

The product is prohibited in any illegal activities. Please use it under local laws and regulations. Our company will not be responsible for any consequences of illegal or improper conducts.

❖ If you have any after sales question, please directly contact with the local distributor.




Image pickup	1/3
TV system	PAL/CCIR NTSC/EIA
Definition	380TV Lines
Scan frequency	PAL/CCIR:50Hz NTSC/EIA:60Hz
Min. illumination	1LUX
Output power	10mW
Output frequency	2.4G
Camera power	DC+8V
Receiver power	DC+12v
Transmission distance without blocking:	200m